

What's in the Box?

NOTE: The photos and instructions were written for a Westerly prop remover for a 1"/25mm propshaft – if you have ordered a tool for a different size propshaft the contents of the box and the instructions are similar, just the sizes will be different.

The contents delivered may also differ slightly in design, size, colour, shape, design, and contents – due to design changes and improvements or the size of kit ordered.

The kit consists of two plates and three threaded rods;



The inboard plate that goes just behind the Prop



The outboard plate that goes outboard of the prop, left hand picture shows the outside view of the plate with the grub screw that is used to centre the plate (where the propshaft has a centre dimple, some don't), and the right hand picture shows the inside of the plate showing the recess and grub screw point, both for centering



How the prop remover looks when put together, just needs a boat, a prop, and a propshaft...

There are three washers under each long nut and they, and the threaded rods, should be greased, using the supplied grease, before use.

Tip: When putting the three threaded rods in place leave the lock nuts on the back of the plate loose until you have lined up the rods with the through holes in the other plate.

Tip: The pointed grub screw is for location only – don't use it to remove the prop